



DELIMER

Lime Scale Remover

DELIMER is an acid blend designed for rapid lime and mineral soil removal. It provides quick penetration of lime soils and free rinsing for exceptional results. It is an excellent choice for the recirculation cleaning of dish machines. This non-fuming acid concentrate may also be used to remove lime or mineral films on other kitchen equipment or utensils. DELIMER can be used at any concentration depending on the severity of the lime being removed.

DIRECTIONS FOR USE

Use this product at 1-2 ounces per 2 gallons of water for general lime control. For an initial treatment on lime, use 2-3 ounces per gallon. Allow areas of heavy lime deposit to soak for several minutes, then brush surface. FOR DISH MACHINES:

- 1. Drain, flush and clean out machine. Never add lime solvent to dish machine containing warewashing detergent.
- 2. Close drain valve, fill tank(s) with hot water.
- 3. Add lime solvent at 4 oz. (1/2 cup) per gallon of water.
- 4. Turn on pumps until lime can be brushed or flushed away.
- 5. Drain tank and flush. Always use rubber gloves when handling.

GENERAL **P**RODUCT **I**NFORMATION

Description: Lime Remover

Safety: Corrosive. Keep product stored in original container, in an upright position, with container tightly closed. Wear protective clothing, gloves, and eye and face protection. If swallowed, rinse mouth - Do Not induce vomiting. If on skin, wash with water - remove contaminated clothing. If inhaled, remove person to fresh air - administer artificial respiration if not breathing. If in eye, flush eye continuously with water - remove contacts and continue flushing with water. Seek medical assistance if symptoms persist. Dispose of contents/container according to local/regional regulations.

For Chemical Emergency, spill, leak, fire, exposure, or accident, contact: Chemtrec (day or night) - Within USA and Canada - 1-800-424-9300.

Packaging: 1 Gal. (3.8L) Case Contents: 4 x 1 Gal. (15.2L)

Product #: 108517

See Safety Data Sheet (SDS) for a complete listing of hazards, precautions, first aid statements, storage and handling information.

SANITECH

Distributed by: **SANITECH**

2335 Buttermilk Crossing, Ste 328 Crescent Springs, KY 41017 • (888) 260-0201 www.Sanitechweb.com

MISCELLANEOUS PRODUCTS

^{*}Please consult your Sales Representative or call (888) 260-0201 for additional use directions.