

Sanitech

LIQUID BREAK



LIQUID BREAK is essential to the performance of the Multi-Component Laundry System. It boosts the cleaning power of the surfactant and softens the hardest water to eliminate scale build-up.

Corrosion inhibitors prevent damage to delicate machine parts. A neutralizer should be added to the pre-rinse when using this builder/break.

DIRECTIONS FOR USE

Directions:

For the following capacity washers, add the amount shown:

200 pound capacity - 4 to 8 oz.

75 pound capacity - 2 to 4 oz.

35 pound capacity - 1 to 2 oz.

Program dispenser to add correct amount with wash water fill. After all items of liquid system are set, run test load of badly soiled and stained linens to observe remarkable cleaning. Check for alkali or acid residue and adjust break or neutralizer as needed.

**Please consult your Sales Representative or call (888) 260-0201 for additional use directions.*

GENERAL PRODUCT INFORMATION

Description: Liquid Laundry Break

Safety: Corrosive. Keep product stored in original container, in an upright position, with container tightly closed. Wear protective clothing, gloves, and eye and face protection. If swallowed, rinse mouth - Do Not induce vomiting. If on skin, wash with water - remove contaminated clothing. If inhaled, remove person to fresh air - administer artificial respiration if not breathing. If in eye, flush eye continuously with water - remove contacts and continue flushing with water. Seek medical assistance if symptoms persist. Dispose of contents/container according to local/regional regulations.

For Chemical Emergency, spill, leak, fire, exposure, or accident, contact: Chemtrec (day or night) - Within USA and Canada - 1-800-424-9300.

Packaging: Net Contents: 5 Gal. (18.927L); 15 Gal. (56.85L)

Product #:10824, 10824C

See Safety Data Sheet (SDS) for a complete listing of hazards, precautions, first aid statements, storage and handling information.

SANITECH

Distributed by:

SANITECH

2335 Buttermilk Crossing, Ste 328

Crescent Springs, KY 41017 • (888) 260-0201

www.Sanitechweb.com